

VI.5.3D-HISTSIM PROGRAM FCST HCL TECHNIQUE HISTSIM

Purpose

Technique HISTSIM sets whether an historical simulation will be performed by Function ESP.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Universal.

Form of Input

HISTSIM(integer)

where integer is 0 or 1 specifying whether or not a historical simulation will be performed

Example

HISTSIM(1)

A historical simulation will be performed.